



NOTES:

1. USE CE25 AND EZBN14 TO ATTACH WIRE MESH TO LADDER TRAY & FFSP AFTER MODIFYING WIRE MESH TO PROPER CONFIGURATION, DRILL HOLES IN FFSP AS NEEDED.
2. SUPPORT WIRE MESH AS SUGGESTED AND END OF LADDER SECTION (ADJACENT WIRE MESH SPLICE AREA) WITHIN 2' OF END OF SPLICE ON LADDER SIDE (not shown).